



## Quick Start Guide

## NEW ACCOUNT INSTRUCTIONS

### UUPlus Personal

Each satellite phone UUPlus supports requires a different modem init string. Select the appropriate modem during the configuration process.

High Bandwidth IP:	+UUPlus UMTF Secure Mail Transport //only for very fast connections
High to Low Bandwidth IP:	+UUPlus VPN Secure IP Connection //use for most IP connections
Iridium (Land line No.):	+Iridium Satellite Phone
Iridium (Iridium No.):	+Iridium to Iridium Call
Mini-M:	+Nera Saturn - WorldPhone - World Communicator +9600 baud Generic Mini-M Phone +2400 baud Mini-M Phone (older)
Inmarsat (not MPDS):	+Fleet 33-55-77
Inmarsat B:	+Inmarsat B Satellite Phone
Globalstar:	+Globalstar GSP-1600 Satellite Phone +Globalstar GSP-2900 Satellite Phone
Thuraya:	+Thuraya Satellite Phone
ACeS:	+ACeS Satellite Phone
Motient:	+Mitsubishi 4800 Baud St-Series Phone +Mitsubishi 2400 Baud St-Series Phone
Optus Sat:	+NEC S2 Satellite Phone

For Cell Phones, use the driver which came with your cell phone's data kit or +14400 baud Cell Phone in the [Available Modems] list.

Place the UUPlus CD in the CD-ROM or run Personal.exe which is available from the website.

1. Place the UUPlus CD in the CD-ROM or run Personal.exe, which can be downloaded from the UUPlus web site <[www.uuplus.com](http://www.uuplus.com)>.
2. From the UUPlus Installation Window, select **[UUPlus Personal]**.
3. Carefully read the 'Welcome to UUPlus Setup' page and click **[Next]**.
4. Carefully read the 'UUPlus Software License Agreement' and click **[Accept]**. You must accept the License Agreement to continue with the installation.
5. Carefully read the 'UUPlus Personal/Personal Pro' readme file for any new information or installation tips and click **[Next]**.
6. The software will want to install to the path "C:\UUPlus". UUPlus software cannot be installed into folders containing a space in their path. Click **[OK]**.
7. Click **[Next]** to install the UUPlus software.
8. After software has successfully copied itself, Personal will launch automatically.
9. A dialog box will appear informing you of your account options. Click **[OK]**.
10. Select **[New]** to create a new account.
11. Before requesting the new account, the modem or IP connection must be configured. Click **[OK]**.
12. On the **[Modem]** tab, select the satellite phone you will be connecting from. If you are using a windows dialup connection, scroll to the bottom of the Available Modems list. Select the appropriate modem and click **[Add]**.
13. On the **[Modem Settings]** tab, select the correct COM Port for your modem and click **[Done Editing Modem]**. If you selected a VPN-xxx modem, this step is skipped.
14. On the **[Calling]** tab click **[Next]**.
15. Next you will be presented with the new user form. Click **[OK]**.
16. UUPlus respects your privacy. Click **[OK]**.
17. Fill out the new user form. From here, you can select a 7-day trial or a paid account. Click **[Done]** when finished.
18. To finish the new account request, click **[Call]**. If you are connected to the Internet, you can request the account through the Internet rather than through your satellite phone. To do so use the arrow buttons in the top right corner to change the dialing location to "VPN.LAN."
19. Once the call is complete, your new account will have been created. Your new UUPlus account is now active and ready to be used.

If you experienced problems calling over your satellite phone, please refer to the modem configuration help files or contact UUPlus support.